

Ash Tray Repair Bracket Installation

**Before installation, be sure to fully read instructions. And most importantly... Take your time installing. OBS Interiors is not responsible for damages or incorrect installation

1. If still installed, remove ash tray. There are 2 screws on either side of the ash tray when it is slid outward, and 1 underneath the dashboard going up into the ash tray from. Once ash tray is being pulled out disconnect any wiring.
2. Assess the damages on the dashboard to be sure there is no severe damages that would cause the repair bracket, or ash tray to no install properly.
3. Remove glove box by opening and squeezing the sides to drop it all the way out.
4. Insert repair bracket from glove box hole and dry fit into proper position.
5. Inside the glove box area on the left (the bracket should meet up on the opposite side of this). Carefully put a mark on the dash where you will drill through the plastic and into the repair bracket. *This is where a rivet will be installed* **SEE PHOTOS ON THE BOTTOM OF INSTRUCTIONS FOR A REFERENCE ON THE UPCOMING STEPS**
6. With a 1/8 inch drill bit, drill through the plastic on your mark. IT IS HIGHLY RECOMMENDED TO STOP AND NOT GO THROUGH THE METAL OF THE REPAIR BRACKET. Ensuring the bracket is properly positioned, you can mark the spot to be drilled with the drill so you can remove it and drill the hole outside of the vehicle.
7. Once the hole is drilled in the bracket and the dashboard, dry fit again ensuring the holes align. Just make sure the bracket is in the proper position. If it does not align, back track your steps to either make a new hole in the bracket that will align.
8. If step 7 goes well, insert a rivet through the dash and bracket. The reason for this is so it helps make sure the bracket doesn't move while holding it in place and that that set of holes will not become misaligned while creating your other holes.

9. About an inch up from your first hole, repeat steps 5-8 to add your second hole that will be for another rivet.
10. On the bottom left corner inside the ash tray area, repeat the same process for another rivet hole.
11. Insert all 3 rivets to hold bracket and make sure everything is lined up properly.
12. Crimp rivets.
13. You can install other rivets if you choose, in our experience with these, we have not had any issues with looseness or the bracket, or any issues with use of the ash tray being pulled in or out just using those 3 rivets.
14. Install ash tray or media hub (whichever you have)



This image is of rivet locations and to demonstrate dry fitment before crimping the rivets, just in case issues need to be addressed. **TAKE YOUR TIME AND DO 1 RIVET HOLE AT A TIME AND THEN DO THIS DRY FIT. IT IS EASIER TO FIX A MISTAKE SOONER THAN LATER.**



This is to give a reference to how the bracket is position is supposed to be from the back side

